



STL

1	TON1
2	SW1/1
3	SW1/2
4	SW1/3
5	SW1/4
6	SW1/5
7	SW1/6
8	SW1/7
9	SW1/8
10	SW1/9
11	SW1/10
12	SW1/11
13	SW1/12
14	SW1/13
15	SW1/14
16	SW1/15
17	SW1/16
18	SW1/17

FILE:167M

*5 Drehschalter
11 Stellungen*

